



**GUIDE:**  
Headset  
installation

**TOOLS YOU NEED:**

- 19mm spanner
- 5mm allen key
- Plastic hammer
- Grease

**Step 1** – Insert bearings, fork, and then the compression ring.



**Step 2** – Place top cover.



**Step 3** – Screw in the expander/top cap using your strong hand!



**Step 4** – Lightly tighten with a 19mm spanner.



**Step 5** – Finish by tightening the expander using a 5mm allen key.



**Step 6** – You have now successfully installed your new headset.



**PREPARING:**

Expander / Top cap



Loosen the top bolt...



... give it a light tap ...



... ready for mounting!  
Remember to grease the threads.